

MH MULT/ MULT TRS

BOM

MH MULT/ MULT TRS PCB and Panel

8x 3.5mm Jacks (Mono for TS version, stereo for TRS version)

8x Jack nuts

Note: This MULT module can be built as either mono (TS) or stereo (TRS). For stereo operation use stereo jacks. The front panel is double-sided so you can either have the name 'MULT' or 'MULT TRS' showing.

Assembly guide

Place the jack sockets on the PCB (Do not solder yet). Note that the jacks share a solder pad for their ground legs. Just push both ground legs through the same hole.

Put the front panel over the jack sockets with the correct version name showing on the front. Secure with the jack nuts.

Check that the jacks are still aligned to the PCB and have not been rotated by tightening the nuts. If any of them are out of place loosen the nut, adjust and retighten.

Solder everything making sure there is no gap between the jack sockets and the PCB.

Done!